

CR-MF5

The **CR-MF5** keypad can operate as:

- **INT-SCR** partition keypad in the **INTEGRA** alarm system
- **ACCO-SCR** keypad with proximity card reader in the **ACCO NET** or **ACCO** access control system
- keypad with proximity card reader in systems of other manufacturers (OSDP, Wiegand)
- standalone door control module

General characteristics:

- user identification by code and/or MIFARE® proximity card
- keypad with white backlight:
 - 12 keys for entering the code
 - 1 function key
- built-in MIFARE proximity card reader (13.56 MHz):
 - Ultralight CSN/SSN
 - Classic CSN/SSN/MSN
 - DESFire (EV1 / EV2 / EV3) CSN/MSN
- supported OSDP protocol (OSDP protocol version 2.2; RS-485 bus)
- additional communication interface
 - INT-SCR (operation in the INTEGRA system)
 - ACCO-SCR (operation in the ACCO NET or ACCO system)
 - Wiegand (operation in other manufacturer's system)
- programming in the CR Soft program
- LED indicators (3 pcs.)
- OC type output (BELL) controlled by the function key
- built-in sounder (volume adjustable)
- optical tamper protection against enclosure opening and removal from the wall
- suitable both for indoor or outdoor installation

Properties for each operation mode:

INT-SCR partition keypad in the INTEGRA alarm system

- functions activated by code and/or proximity card:
 - arming/disarming and alarm cancelling in partition
 - door opening
 - control of 24. *MONO switch* and 25. *BI switch* type outputs
 - confirmation of guard round
 - activation of the temporary partition blocking function
 - bypassing cash machine zones
 - code change by the user
- functions activated without using a code / proximity card:
 - quick arming
 - alarm triggering from the keypad
 - alarm muting on the keypad
- controlling access to a single door
- activation of an additional function using the function key (BELL)
- relay output for controlling an electric strike, electromagnetic lock or other device which activates the door
- door status input



- request-to-exit input
- configuration of the INT-SCR keypad settings – using the DLOADX program or the keypad

ACCO-SCR keypad with proximity card reader in the ACCO NET or ACCO access control system

- functions activated by code and/or proximity card:
 - door opening
 - blocking / unblocking a door
- activation of an additional function using the function key (BELL)
- configuration of the ACCO-SCR keypad settings using the ACCO Soft (ACCO NET system) / ACCO SOFT-LT program (ACCO system)

Keypad with proximity card reader in systems of other manufacturer

- selection of the communication interface:
 - OSDP (RS-485 bus)
 - Wiegand
- activation of an additional function using the function key (BELL)

Standalone door control module

- support for up to 128 codes
- support for up to 128 proximity cards
- functions activated using a code / proximity card:
 - door opening
 - blocking / unblocking a door
 - code change by the user
- possibility to specify the number of times a card/code is used
- activation of an additional function using the function key (BELL)
- relay output to control an electric door strike, magnetic lock or other device activating a door
- door status input
- request-to-exit input

Supply voltage	12 V DC
Operating temperature range	-25°C...+55°C
Standby mode current consumption	65 mA
Max. current consumption	115 mA
Weight	129 g
Maximum humidity	93±3%
Dimensions	47 x 158 x 30 mm
Relay output (resistive load)	1 A / 30 V DC
	30 mA / 12 V DC
	13,553...13,567 MHz
	up to 55 mm

